

installation step



1

make the curved line
connected to the pop filter



2

After the fixed, make the
curved line through
microphone shock mount,
fasten it behind the top
screws, the installation
will be finish